

REPLACEMENT PARTS LIST

SINGLE PACKAGE AIR CONDITIONER

P8SE SERIES

14 SEER



IMPORTANT

- This document is primarily intended to assist qualified individuals experienced in the proper repair or servicing of this appliance. Only factory authorized parts or accessory kits may be used with this product. Improper installation, service, adjustment, or maintenance may cause explosion, fire, electrical shock or other hazardous conditions which may result in personal injury or property damage.
- Some local codes require licensed installation / service personnel to service this type of equipment. Under no circumstances should the equipment owner attempt to install parts or service this equipment. Failure to comply with this warning could result in property damage, personal injury, or death.

P8SE SERIES SINGLE PACKAGE AIR CONDITIONER

ITEM	DESCRIPTION	P8SE-X36K	P8SE-X48K	P8SE-X60K
		922475	922476	922477
1	PANEL, FRONT	298891R	298891R	298893R
2	SERVICE PANEL	D05111	D05111	D05113R
3	CORNER PANEL ASSEMBLY	M0104900R	M0104900R	292436R
4	BLOWER PANEL ASSEMBLY	D05548R	D05548R	D05543R
5	SUPPLY PANEL ASSEMBLY	M0105000R	M0105000R	D05556R
6	RETURN PANEL ASSEMBLY	D05567R	D05567R	D05566R
7	TOP PAN	292441R	292441R	292441R
8	POST, CORNER	D09994R	D09994	D09997R
9	RAIL, BASE, 47.23	277551R	277551R	277551R
	RAIL, BASE, 55.63	277552R	277552	277552
10	DUCT CAP ASSEMBLY	D05530R	D05530R	D05530R
11	BOTTOM PAN ASSEMBLY	D05480R	D05480R	D05480R
12	BLOWER HOUSING ASSEMBLY	297219R	297219R	297219R
13	WHEEL, BLOWER	667260R	667260R	667260R
14	BLOWER MOTOR, 1/2 HP	M0009014R	-	-
	BLOWER MOTOR, 3/4 HP	-	M0109800R	M0106800R
15	PANEL, BLOWER TRANS SIDE	D05450	D05450	D05450
16	PANEL, ELECTRIC HEAT	D05420	D05420	D05420
17	PANEL, BLOWER TRANSITION	283942R	283942R	283942R
18	FAN, BLADE	667278R	667278R	667278R
19	MTR, FAN, PSC, 1/4 HP	621990R	621990R	621990R
20	DROP-IN ORIFICE	263210R	263210	263210
21	GRILLE, TOP-24"	669404R	669404R	669404R
22	PANEL, CLOSE-OFF ASSEMBLY	292429	292429	292423
23	CONTROL PANEL ASSEMBLY	M0106500R	M0106500R	292405R
24	PANEL, CONTROL	2A9611	2A9611	2A9611
25	DIVIDER PANEL, LOW VOLTAGE	2A9691	2A9691	2A9691
26	RELAY	621867R	621867R	621867R
27	BLOCK, TERMINAL, 2 POLE	632214R	632214R	632214R
	BLOCK, TERMINAL, 7 PIN	632695R	632695R	632695R
28	CONTACTOR, 1 POLE, 25FLA	624826	-	-
	CONTACTOR, 1 POLE, 30FLA	-	624827	-
	CONTACTOR, 1 POLE, 40FLA	-	-	624828
29	DUAL GROUNDING LUG	632235R	632235R	632235R
30	CAPAC, RUN 45/7.5/370	621153	-	-
	CAPAC, RUN 70/7.5/370	-	621944	-
	CAPAC, RUN 80/7.5/370	-	-	621717R
31	TRANSFORMER	622336R	622336R	622336R
32	BRACKET, EXT. SERVICE PORTS	298552	298552	298552
33	FITTING, PANEL MNT, STD, 3/8"	664696	664696	664696
34	COMPRESSOR, ZP31K5E-PFV	921427	-	-
	COMPRESSOR, ZP42K5E-PFV	-	921466	-
	COMPRESSOR, ZP54K5E-PFV	-	-	921468
35	FITTING, ACCESS	663812R	663812R	663812R

Please specify the correct Model No., Serial No, and part number(s) when ordering parts from the nearest authorized dealer or service center.

P8SE SERIES SINGLE PACKAGE AIR CONDITIONER

ITEM	DESCRIPTION	P8SE-X36K	P8SE-X48K	P8SE-X60K
		922475	922476	922477
36	DRIER, FILTER, UNIFLOW, 8IN^3	669764	669764	669764
37	THERMAL EXPANSION VALVE	664343R	664349R	664350R
38	DISTRIBUTOR	664588R	664588R	664588R
39	STAND, DRAIN PAN	D05440	D05440	D05440
40	DRAIN PAN ASSEMBLY	669190R	669190R	669190R
41	COIL, INDOOR	664935R	664935R	664937R
42	DIVIDER PANEL ASSEMBLY	292485R	292485R	292483R
43	COIL, OUTDOOR	2C2311R	2C2311R	2C2301R
44	DRAIN TUBE	663833	663833	663833
45	OUTDOOR COIL GUARD	2A8452R	2A8452R	2A8454R
46	OUTDOOR HAIL GUARD	669223	669223	917206
47	FUSE, 3-AMP (NOT SHOWN)	632261R	632261R	632261R
48	SWITCH, HIGH PRESSURE (NOT SHOWN)	632473R	632473R	632473R
49	SWITCH, LOW PRESSURE (NOT SHOWN)	632393R	632393R	632393R
50	PLUG, MOLDED, HV (NOT SHOWN)	634715	634715	634715
51	CORE, CHARGING PORT (NOT SHOWN)	662103R	662103R	662103R
52	CAP, CHARGING PORT (NOT SHOWN)	663818R	663818R	663818R
53	PAINT, TOUCH UP, STERLING GREY (NOT SHOWN)	903598	903598	903598
54	SET OF WIRES (NOT SHOWN)	M0038326R	M0038326R	M0038326R

Please specify the correct Model No., Serial No, and part number(s) when ordering parts from the nearest authorized dealer or service center.

